



twentytwodesigns.com

TeleBulldog Mounting Template

Chord
Center

Midline
of Ski

Mounting Steps:

- 1) Find and mark chord center.
- 2) Tape the template to the ski after aligning a number matched pair of lines over the ski edges and aligning the chord center line over the chord center mark. *This is the most important step so please take plenty of time to align the template correctly.*
- 3) Center punch the 4 toeplate mounting holes.
- 4) Align the boot pin holes over the chord center and mark the back of the boot heel.
- 5) Reposition the template so that the back of boot heel line is over the boot heel mark.
- 6) Center punch the 2 heel plate mounting holes.
- 7) Drill all six holes 3/8" deep.
- 8) Fill holes with waterproof glue.
- 9) Screw the shim and toeplate down.
- 10) Hold heel plate, bale, and key piece together, then screw the heel plate down.

Midline
of Ski